

User Guide

Power Module 30 kW

Please completely read this document and the contained safety instructions and note all given information before usage.

Please maintain the confidentiality of this user guide. It is intended solely for usage by people professionally associated with the product. If you are not the intended recipient, you may not disclose or use the information in this documentation. The information does not constitute an offer or solicitation to buy or sale of any security.

This user guide's text and illustrations have been meticulously crafted. However, we may not be held accountable for any discrepancies or failure consequences.

Some company and label names are protected by a label, a patent, or a trademark.

Copyright ©

Address: Bacancy Systems PVT LTD,
15-16, Times Corporate Park,
Near Thaltej-Shilaj Road,
Opp. Copper Stone Flats,
Thaltej, Ahmedabad,
Gujarat, India, 380059

Website: www.bacancysystems.com

Email: systems@bacancysystems.com

Phone: +91 90160 28817

All rights reserved, including disposal, exploitation, reproduction, editing, distribution, as well as and utilisation for intellectual property rights.

Liability

The given data is primarily for product description reasons and should not be considered a guaranteed characteristic unless specifically stated in the contract. All rights are retained with regard to the content of this documentation and the availability of the product.

DISCLAIMER

The product, product data and any of its specifications are subject to change without notice. Bacancy Systems PVT LTD, its employees, and all persons acting on its behalf shall not be liable for any errors, inaccuracies, or incompleteness that occur if the methodology contained herein or in any other revelation of the product is not followed. The product specifications alter or amend neither the terms nor conditions of purchase nor the warranty expressed therein.

Bacancy Systems PVT LTD offers no warranty, representation, or guarantee other than as set forth in the terms and conditions of purchase. To the maximum extent permitted by applicable law.

Bacancy Systems PVT LTD, Disclaims

- (i). Any and all liability arising out of the application or use of any product.
- (ii). Any and all liability, including without limitation special, consequential or incidental damages
- (iii). Any and all implied warranties, including those of merchantability, fitness for a specific purpose, and non-infringement.

The information provided in user guide and/or specifications may differ from actual results in different circumstances, and efficiency may change over time. Statements on a product's appropriateness for a certain application are based on Bacancy Systems PVT LTD's understanding of standard demands that are frequently put on the products of Bacancy Systems PVT LTD. The customer should determine whether a given Bacancy Systems PVT LTD product with the features mentioned in the product specification is appropriate for use in a specific application.

The product shown herein is not designed for use in lifesaving or life-sustaining applications unless otherwise expressly indicated. Customers who utilise or sell Bacancy Systems PVT LTD products that are not explicitly intended for such applications do so solely at their own risk.

This user guide is intended to improve the operator's efficiency throughout the procedure and does not entirely absolve them of responsibility.

Change Record

Rev. No.	Date	Details	Revised By	Approved By
0	09/10/2024	Initial Release	Rajkumar Patel	Jasmin Nakrani
1	04/11/2024	Section 5.2.4 Pin Configuration	Rajkumar Patel	Jasmin Nakrani
2	23/04/2025	Legal Entity Conversion: LLP to PVT LTD	Rajkumar Patel	Jasmin Nakrani
3	30/06/2025	Updated: Section 6, 7 & 8	Rajkumar Patel	Jasmin Nakrani
4	01/05/2026	Revised Email Address	Rajkumar Patel	Jasmin Nakrani

Table of Contents

1. About this Document.....	9
1.1 Information on the User Guide.....	9
1.2 Limitations of Liability.....	9
2. Safety.....	10
2.1 Safety Graphical Pictogram or Symbol	10
2.2 Safety Instruction and Warnings	11
2.3 The Responsibility of Operator	12
2.4 Person in Charge of Operations	12
2.5 In an occurrence of Danger or an Accident.....	13
3. Packaging, Transport and Storage.....	14
3.1 Inspection, Packaging and Transport.....	14
3.2 Transport.....	14
3.3 Storage.....	14
4. Intended Use	15
4.1 Limitation	15
4.2 Alteration and Restoration of the Product/System.....	15
5. Structure and Function.....	16
5.1 Overview	17
5.1.1 Feature	17
5.1.2 Application	17
5.2 Function.....	17
5.2.1 Technical Specification	17
5.2.2 Performance Curve.....	20
A. Input Voltage Curve	20
B. Output Voltage Curve	20
5.2.3 Block Diagram	21
5.2.4 Pin Configuration	22
A. Input Connector	22
B. Output Connector.....	22
C. Extension of Output Connector	23
5.2.5 Mechanical Diagram	24
6. Installation.....	26
6.1 Module	26
6.2 Connector.....	26
6.2.1 Connector Position and Size.....	27

6.3	Cable Selection	28
7.	Operating Status	30
7.1	Power Module Panel.....	30
7.2	Button.....	30
7.3	Indicator LED Light	33
A.	State Grid Protocol Indicator	33
B.	Bacancy Agreement Indicator	34
8.	Operating Environment	36
A.	Heat Dissipation	37
B.	Reference Design for Heat Dissipation of Power Module	39
9.	Maintenance	41
9.1	Preventive Instruction	41
9.2	Replacement	41
10.	Appendix	43
10.1	Dispose of Product	43
10.2	Abbreviations and Glossary	43

List of Figures

Figure 1 Safety Instruction	10
Figure 2 Power Module 30kW	16
Figure 3 Input Voltage / Output Power Curve	20
Figure 4 Output Voltage / Output Current Curve	20
Figure 5 Input Connector	22
Figure 6 Output Connector.....	22
Figure 7 Extension of Output Connector	23
Figure 8 The Connector of Power Module Installation.....	26
Figure 9 Connector Position and Size.....	27
Figure 10 Reference Diagram:	27
Figure 11 AC Input Connector Size.....	27
Figure 13 DC Input Connector Size.....	27
Figure 12 Reference Diagram:	27
Figure 14 Power Module Panel.....	30
Figure 15 Information Display Flow.....	30

List of Tables

Table 1 Safety Graphical Pictogram or Symbol	10
Table 2 Input Connector.....	22
Table 3 Output Connector	22
Table 4 Extension of Output Connector	23
Table 5 Type and Specification for Cable.....	28
Table 6 Navigation Button	30
Table 7 Operation Buttons	31
Table 8 Definition of Indicator LED Light	33
Table 9 Definition of State Grid Protocol Indicator	33
Table 10 Definition of Bacancy Agreement Indicator	34
Table 11 LED Status and Its Meaning	35

1. About this Document

1.1 Information on the User Guide

This user guide contains basic information to be considered in the utilisation of the product. A precondition for safe working is the observance of all stated safety instructions and directions. Therefore, this user guide should be read and applied without fail by any person assigned to the installation and operating procedures of the product or system.

This user guide is part of the product, and the case may have to be passed to third parties or the following owners. It must be permanently kept at the usage site and be available for the operating personnel who are responsible for the installation of this product or system.

We are eager to ensure the comprehensiveness, relevance, and up-to-dateness of this user guide. It may become essential to make spontaneous changes to the product and its operation, which may not align with this manual, to maintain our technical advancement. In that case, Bacancy Systems PVT LTD will provide you with a new manual. We exclude liability for disturbances, failures, and resulting damages.

The illustrations in this user guide will provide a better understanding. It can occur that illustrations are not drawn to scale or deviate somewhat from the original.

1.2 Limitations of Liability

All statements and remarks in this user guide have been aggregated with consideration of current standards, laws, and regulations, the state of technology, as well as our extensive knowledge, long-time expertise, and experience. In special models, due to demands for additional order options or the latest technical alterations, the actual scope of delivery can differ from the explanations and elaborations described here.

The manufacturer excludes any liability for damages caused by:

- Inappropriate assembling and installation.
- Non-observance of the user manual.
- Non-intended and improper use.
- Use beyond operation limits.
- Deployment of insufficiently qualified and trained personnel.
- Use of unauthorised spare parts and accessories.

2. Safety

The safety directions, cautions, warnings, and notices are stated here. Moreover, in this user guide's section, the following sections have to be followed to reduce potential health risks and prevent hazardous situations as per the ISO 45001:2018 standard for occupational health and safety.

2.1 Safety Graphical Pictogram or Symbol

These prescribe safety signs for the purposes of accident prevention, fire protection, health hazard information, and emergency evacuation as per the ISO 7010:2019 standard for graphical symbols, safety colours, and registered safety signs.

The safety instructions are structured as follows:














Figure 1 Safety Instruction


Table 1 Safety Graphical Pictogram or Symbol


Pictogram / Symbol	Signal Word	Meaning
	DANGER!	In case of non-compliance with this safety instruction, death or serious injury will occur.
	WARNING!	In case of non-compliance with this safety instruction, death or serious injury can occur.
	CAUTION!	In case of non-compliance with this safety instruction, a minor or moderate injury can occur.
	NOTICE!	In case of non-compliance with this safety instruction, material damage can occur.
	NOTE!	Useful notice or tip on the products or system's easy operation.


2.2 Safety Instruction and Warnings

MANDATORY	Read User Guide
	To get an understanding of the product, the user should pay careful attention to the user guide.
PROHIBITION	Hot Works
	Hot work shall be prohibited in close proximity to fully charged batteries. It will result in a battery explosion.
CAUTION!	Working with Machine Tools Near the Battery
	To prevent the occurrence of sparks, short circuits, or explosions, the user shall take precautions near the operation of a machine tool with a battery.
PROHIBITION	Metallic Articles
	Metallic articles such as watches, bracelets, rings, necklaces and others shall be wear prohibited during the installation, operation and maintenance.
PROHIBITION	Installation Environment Circumstance
	High concentrations of oxidising or salted gases, wet or dusty surfaces, proximity to sources of extreme heat, open flames, or sparks, or high variation with temperature, proximity to storage of highly flammable materials or gas concentrations, and proximity to areas unprotected from water or high humidity are all prohibited.
MANDATORY	Special Insulated Tool
	While installation, operation and maintenance the user shall be mandatory to use special insulated tools.

MANDATORY	Installation and Maintenance
	Installation and maintenance should be carried out under the supervision or advice of a qualified professional.

PROHIBITION	Assembly and Disassembly
	The assembly or disassembly of an open, repaired, default parameter, or changed production should be prohibited. The warranty could be void and invalid, and the service can be discontinued without notice. The use of a high-pressure washer to clean the product is prohibited.


MANDATORY	Disconnect Power Supply
	The power source or plug should be disconnected in the event of an unanticipated event or when conducting maintenance and repair.

FIRE PROTECTION	Fire Extinguisher
	In the event of a fire, the use of a dry powder fire extinguisher should be advised for fire control, and the use of water should be prohibited.

2.3 The Responsibility of the Operator

The product is associated with industrial safety standards. However, the operator who is installing or operating the product is liable for the legal responsibilities for operational safety. In addition to the operational safety instructions in this manual, the safety, accident prevention, and environmental protection regulations valid for the operational area of the product shall be followed.

2.4 Person in Charge of Operations

WARNING!	Risk of injury caused by a lack of an adequate qualification!
	Inappropriate handling of the product can lead to severe personal injuries and material damage.

In this manual the following qualification are specified:

Instructed Person	An instructed person is someone who has been instructed by the operator or manufacturer on the given tasks and potential hazards in the event of incorrect behaviour, as well as being semi-skilled and knowledgeable about the necessary safety procedures and safeguards.
Qualified Specialised Professional	Qualified specialised professionals are individuals who are knowledgeable with the assembly, commissioning, and operation of the product and process qualifications related to their work. The specialised individual is able to recognise hazards and prevent potential hazards because of their professional training, knowledge, and experience, as well as their understanding of the appropriate regulations.

2.5 In an occurrence of Danger or an Accident

Preventive Measures:

- Always be prepared for accidents or fires!
- Keep first-aid equipment (ambulance boxes, blankets, etc.) within easy reach.
- Inform personnel with accident alerting, first-aid, and emergency services.
- Keep clear access routes for emergency vehicles.

If the occurrence happens, follow these steps:

- Turn off the product immediately.
- Implement first-aid procedures.
- Get people out of hazardous areas.
- Inform the appropriate person at the usage spot.
- Contact a doctor and/or the fire department.

3. Packaging, Transport and Storage

3.1 Inspection, Packaging and Transport

The products have been properly secured to ensure sufficient safeguarding during shipment. Please scrutinise the delivered products for overall quality and transportation problems as soon as possible.

In the instance of external shipment damage, proceed as follows:

- Do not accept delivery or accept it only on reserve.
- Issue a complaint.
- Do not use items that are obviously defective.

3.2 Transport

Always ensure that your equipment is transported in safe and appropriate containers while transporting it to the usage location or in the field.

Never transfer everything in an unplanned way in the vehicle. Hits and thrusts might seriously impair the product's functionality.

Always use the original packaging, transport containers, transport boxes, or equivalent packaging, whether transporting by train, aircraft, or ship. The container shields the goods from impacts and vibrations.

3.3 Storage

Strictly store the product in well-ventilated, dry spaces. During storage, keep it dry and leverage the original packaging if possible.

Avoid extreme heat fluctuations during storage. The initiation of water condensation can impair the product's operation.

When storing, keep in mind the temperature restrictions of the product. Please refer to the product's technical data for valid storage temperatures.

4. Intended Use

The purpose of this user guide is to give you basic information about the power module 30kW. This user guide is mainly focused on the technical aspects of the power module, which are covered in this user guide in graphical and tabular formats in various sections, as listed below:


Sections one to three featured information concerning the document and product's liability, safety, packing, transportation, and storage constraints. These first three parts will help you know how to follow pre-conception practises that must be followed before, during, and after utilising the product.

Section five contains technical information about the power module, such as its functions, features, and applications, as well as technical specifications, a performance curve, and a block diagram of the module's internal architecture, including the communication protocol, interface, and functions. Describe how to setup and integrate power module with additional components and mechanical dimensions that will help users understand the installation.

Section six describes the operating status of the power module, including LED status and meaning, as well as information about the status on display during usage with the button.

Sections seven and eight describe the power module's operating environment and maintenance.

Finally, the appendix section included dispose of product, abbreviation, and glossary, as well as the company's help desk and contact information.

WARNING!	Risk caused by inappropriate use!
	<p>Any unconventional use and/or different operation of the product can lead to hazardous situations.</p> <ul style="list-style-type: none"> • Only use the product in a conventional manner.

4.1 Limitation

The product is intended for use in an operational environment. It should not be used in hostile or explosive conditions.

The operator should consult local safety authorities and safety representatives before performing tasks in hazardous areas or in similar circumstances.

4.2 Alteration and Restoration of the Product/System

To prevent risks and make sure optimal performance, no alterations, attachments, or restoration of the product are permitted without explicit authorisation of Bacancy Systems PVT LTD.

5. Structure and Function



Figure 2 Power Module 30kW


The power module is a high-efficiency, high-power-density AC/DC module specifically engineered by Bacancy Systems PVT LTD for electric vehicle (EV) fast charging applications. This module operates on a three-phase (3P+N+PE) and supports an input voltage range of 285 to 475 VAC. It delivers a rated output power of 30kW, with a constant power range spanning from 250 to 1000 VDC.

The charging module communicates with the main monitoring system via the CAN protocol for enabling comprehensive parameter adjustments, operational data acquisition, and management of the module's functioning status. This connection ensures that the charging process is managed efficiently and precisely to improve the EV fast charging infrastructure's overall reliability and performance.

This advanced module is designed to meet the demanding requirements of modern EV fast charging stations, providing a robust and efficient solution for high-power charging applications.

- **Module Identification Nomenclature**

TH 30 F 10025 C 7



5.1 Overview

5.1.1 Feature

List of Feature

Digital technology, current sharing imbalance for modules parallel < $\pm 5\%$
Quick plug and install
Input and output power supply protection
Intelligent fan speed control
Support parallel voltage regulation and current regulation function
Ambient temperature detection and protection
Group current sharing function

5.1.2 Application

List of Applications

Fast Charging Station, On-board Charger and Battery Charger

5.2 Function

5.2.1 Technical Specification

Product Properties

Product Type	Power Module 30 kW
Product Family	Power Module

Input Electrical Properties

Voltage	380 VAC $\pm 10\%$ (3P+N+PE)
Voltage Range	285 to 475 VAC
Frequency Range	50 to 60 Hz $\pm 10\%$
Power Factor	≥ 0.99 (30% to 100% Load)
Total Harmonic Distortion (THD)	$\leq 5\%$ (50% to 100% Load)
Standby Power Consumption	< 13 W

Output Electrical Properties

Voltage Range	50 to 1000 VDC
Current Range	0.5 to 120 A
Constant Power Interval	250 to 500 VDC 500 to 1000 VDC (Automatic Switching)

Other Electrical Properties

Voltage Stabilisation Accuracy	$\leq \pm 0.5\%$	
Current Stabilisation Accuracy	$\leq \pm 1\%$	(In the range of 20 % rated output current to maximum output Current.)
Effective Value Coefficient of Output Ripple	$\leq \pm 0.5\%$	(In the output voltage range of 200 to 1000 VDC)
Current Sharing Imbalance for Modules in Parallel	$\leq \pm 5\%$	(Parallel Average Current should be more than 5A)
Peak Efficiency	$\geq 96\%$	
Soft Start Time	3 to 8 s	

Input Protection		
Over Voltage Protection Point	490 ± 10 VAC	
Over Voltage Recovery Point	475 ± 10 VAC	
Under Voltage Protection Point	270 ± 10 VAC	
Under Voltage Recovery Point	285 ± 10 VAC	
Fan Fault	Yes	(The fan is malfunctioning and has shut down. After recovery, the user must send a command to start.)
Input Phase Absence protection	Yes	(The input phase absence is shut down. After recovery, the user must send a command to start.)
Output Protection		
Short-Circuit Protection	Yes	(The short-circuit protection is shut down and locked. To restore, the user must repower the module.)
Over-Current Protection	Yes	(The over-current protection is shut down and locked. After recovery, the user must send a command to start.)
Over-Voltage Protection	1020 ± 10 VDC	(Double overvoltage protection at the hardware and software level is shut down and locked. To restore, the user must repower the module.)
Communication		
Protocol	CAN	
Ambient Condition		
Degree of Protection	IP20	
Operating Temperature	-30°C to 75°C	(Above 55°C, output derating. Above 75°C, over temperature shut down.)
Storage / Transport Temperature	-40°C to 75°C	
Permissible Humidity	5 to 95 %	(No Condensation)
Noise	≤ 65 dB	(The mute mode can be set for the upper computer, and the noise in the mute mode is ≤ 55 dB.)

Support

Prevent Current Rewinding

Mechanical Properties

 Dimension
 (With connectors, without handles and raised front panel) 437.5 (L) X 300 (W) X 84 (H) mm

Weight ≤ 16 kg

Other

Insulation Strength	Input to Enclosure	(In normal test environment, use 1000V insulation resistance test equipment, insulation resistance >1000 MΩ)
	Input to Output	
Output to Enclosure		
Input to Communication		
Output to Communication		
Dielectric	Communication to Enclosure	(In normal test environment, use 250V insulation resistance test equipment, insulation resistance >10 MΩ)
	Input to Enclosure	(4200 VDC A constant leakage current of less than 10mA for one minute does not cause insulation failure or flashover.)
Input to Output		
Output to Enclosure		
Input to Communication		
Output to Communication		
	Communication to Enclosure	(1500 VDC A constant leakage current of less than 10mA for one minute does not cause insulation failure or flashover.)

5.2.2 Performance Curve

A. Input Voltage Curve




Figure 3 Input Voltage / Output Power Curve

B. Output Voltage Curve





Figure 4 Output Voltage / Output Current Curve

5.2.3 Block Diagram



5.2.4 Pin Configuration

A. Input Connector




Figure 5 Input Connector

Table 2 Input Connector

Pin	Signal Name	Description
1	W	AC-C Phase Input Power Supply
2	V	AC-B Phase Input Power Supply
3	U	AC-A Phase Input Power Supply
4	PE	Input Earthing

B. Output Connector




Figure 6 Output Connector

Table 3 Output Connector

Pin	Signal Name	Description
1	CAN H	CAN High Communication
2	CAN L	CAN Low Communication
3	Empty	-
4	Empty	-
5	Reserved	For Hot Swap
6	Reserved	For Hot Swap
7	Estop +	Emergency Stop Input Signal Positive
8	Estop -	Emergency Stop Input Signal Negative
9	Empty	-
10	Output Negative	Output Negative Power Supply
11	Output Negative	Output Negative Power Supply
12	Empty	-
13	Output Positive	Output Positive Power Supply
14	Output Positive	Output Positive Power Supply

C. Extension of Output Connector






Figure 7 Extension of Output Connector


Table 4 Extension of Output Connector


Pin	Signal Name	Description
J1-1	CAN L	CAN Low Communication
J1-2	CAN H	CAN High Communication
J2-1	CAN L	CAN Low Communication
J2-2	CAN H	CAN High Communication
J3-1	ESTOP+	Emergency Stop Input Signal Positive
J3-2	ESTOP-	Emergency Stop Input Signal Negative
J4-1	ESTOP+	Emergency Stop Input Signal Positive
J4-2	ESTOP-	Emergency Stop Input Signal Negative
J5	Reserve	-
J6	Reserve	-
J7	Jumper Terminal	<ul style="list-style-type: none"> 1 & 2 short circuit, Matching Resistance Access 2 & 3 short circuit, Matching Resistance not Access

MANDATORY	Power Module Installation Position
	While installation, operation, and maintenance, the user shall be required to install the power module in a horizontal position.

5.2.5 Mechanical Diagram





NOTE!	Customise the Front Panel
	<p>The user can contact Bacancy Systems to customise the front panel without adding handle and lock.</p>

6. Installation

6.1 Module

The instructions below describe how to install a power module.

1. With both hands, place the power module into the appropriate location in the cabinet.
2. Gently put the power module into its appropriate position, to ensure the connector is properly connected.
3. Tighten the two screws holding the power module's front panel to the cabinet.

6.2 Connector

When determining the aperture size of the power module terminal mounting panel, consideration should be given to assembly errors to the power module side terminals as well as machining errors to the power module itself, with a specific tolerance incorporated into the design.




Figure 8 The Connector of Power Module Installation.

6.2.1 Connector Position and Size




Figure 9 Connector Position and Size.




Figure 11 AC Input Connector Size.




Figure 10 Reference Diagram:
AC Input Connector.




Figure 13 DC Input Connector Size.




Figure 12 Reference Diagram:
DC Input Connector.

All dimensions are in "mm".


The connecting terminals should be put on the inside side of the subframe sheet metal, with the screws fastened from the inside out. To prevent inappropriate installation of the power module and poor connection contacts due to interference with the chassis, use installation screws with a thread length of < 4mm.



6.3 Cable Selection

The specifications of the charging station's essential electrical components must be developed in accordance with the power module standards. At the same time, future power demand of the charging station should be addressed. Compatibility should be addressed while selecting devices, cables, and copper bus flow. Leaving apart the necessary power and structural interface, the primary elements influencing the specifications of important electrical components in the charging module are as follows:

1. The AC input cable is considered based on the maximum input current. (When the AC input line voltage reaches the minimum voltage of the full power output of the power module, the current becomes the maximum input current at the time.)
2. The DC output cable is considered based on the power module's maximum output current.
3. Shielded cables are suitable for communication purposes.
4. The wire harness is cold pressed. It is advised to use six-sided crimping pliers for the crimp tool. Single-sided crimping is not permitted, as it could damage the crimping hole.

Table 5 Type and Specification for Cable

Type	Specification		
AC Input Power Line			
	No.	Model	Quantity
	1	Connector Socket	1
	2	5 hole Pressing	4
	3	25 mm 8 Black Heat Shrink Tube	4
	4	ZRBVR-10.0mm ² (Red) /Z-BVR 10 (Red)	1
	5	ZRBVR-10.0mm ² (Green) /Z-BVR 10 (Green)	1
	6	ZRBVR-10.0mm ² (Yellow) /Z-BVR 10 (Yellow)	1
7	ZRBVR-10.0mm ² (Y-G) /Z-BVR 10 (Y-G)	1	

<p>DC Output Power Line</p>																																		
	<table border="1"> <thead> <tr> <th>No.</th> <th>Model</th> <th>Quantity</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Connector Socket</td> <td>1</td> </tr> <tr> <td>2</td> <td>5 hole Pressing</td> <td>4</td> </tr> <tr> <td>3</td> <td>ZR-RV10 Tinning Blue</td> <td>2</td> </tr> <tr> <td>4</td> <td>ZR-RV10 Tinning Brown</td> <td>2</td> </tr> <tr> <td>5</td> <td>25mm 8 Black Heat Shrink Tube</td> <td>4</td> </tr> <tr> <td>3</td> <td>TH30F10025C7-2-ZJBX10 1.0 Adaptor Plate</td> <td>1</td> </tr> <tr> <td>7</td> <td>Metal Film Resistance RJ14-1/4W-120ΩF</td> <td>1</td> </tr> <tr> <td>8</td> <td>Single Row Straight Pin Seat 2.54 1*3P L=11.6</td> <td>1</td> </tr> <tr> <td>9</td> <td>Short-Circuit Connector 2.54-2</td> <td>1</td> </tr> <tr> <td>10</td> <td>Connector Seat TJC3-2A</td> <td>6</td> </tr> </tbody> </table>	No.	Model	Quantity	1	Connector Socket	1	2	5 hole Pressing	4	3	ZR-RV10 Tinning Blue	2	4	ZR-RV10 Tinning Brown	2	5	25mm 8 Black Heat Shrink Tube	4	3	TH30F10025C7-2-ZJBX10 1.0 Adaptor Plate	1	7	Metal Film Resistance RJ14-1/4W-120ΩF	1	8	Single Row Straight Pin Seat 2.54 1*3P L=11.6	1	9	Short-Circuit Connector 2.54-2	1	10	Connector Seat TJC3-2A	6
No.	Model	Quantity																																
1	Connector Socket	1																																
2	5 hole Pressing	4																																
3	ZR-RV10 Tinning Blue	2																																
4	ZR-RV10 Tinning Brown	2																																
5	25mm 8 Black Heat Shrink Tube	4																																
3	TH30F10025C7-2-ZJBX10 1.0 Adaptor Plate	1																																
7	Metal Film Resistance RJ14-1/4W-120ΩF	1																																
8	Single Row Straight Pin Seat 2.54 1*3P L=11.6	1																																
9	Short-Circuit Connector 2.54-2	1																																
10	Connector Seat TJC3-2A	6																																
<p>CAN Communication Line</p>	<p>0.3 mm² (22AWG) twisted-pair shielded flame-retardant cable with a voltage resistance of 60VDC and a temperature range of -40°C to 105°C.</p>																																	
<p>Crimp Tool</p>																																		

7. Operating Status

7.1 Power Module Panel

There are buttons, a digital tube and indicator lights on the panel of the power module.




Figure 14 Power Module Panel.

7.2 Button

To configure the power module, use the two up and down buttons to alter the display content and adjust the set value.

Table 6 Navigation Button

No.	Function	Press	Button	Description
1	Parameter Switch	Short Press	▲ or ▼	To get parameter-related information in succession.
2	Setting Menu	Press Hold (2.5 S)	▲ or ▼	Enter the settings menu.
3	Setting Parameter	Short Press	▲ or ▼	To increase and decrease setting parameters.
4	Parameter Value	Press Hold (2.5 S)	▲	To change the parameter value digit (one/ten/hundred).
5	Save Present Setting	Press Hold (2.5 S)	▼	To save the current setting up parameters and proceed to the display page.




Figure 15 Information Display Flow.

Table 7 Operation Buttons




No.	Function	Press	Button	Description	
1	View Information	Short Press	▲ or ▼	To view module information.	
2	Display Page	Short Press	▲ or ▼	To switch displayed pages in the sequence.	
		Press Hold (2.5 S) The interface starts to blink	▲ or ▼	To enter the setting screen from the display screen.	
3	Set Interface	Short Press	▲ or ▼	To increase or decrease the setting parameter.	
		Press Hold (2.5 S) The interface blinking position changes	▲	To modify the parameter value digit (One, Ten, or Hundred).	
		Press Hold (2.5 S)	▼	To save the present setting parameter and move forward to the display page.	
4	Address Setting	Using 80H to replace 91H as an example:			
		1	Press Hold (2.5 S)	▲ or ▼	The interface appears for 80H or The interface flashes ("0").
		2	Short Press	▲	80H to change in 81H
		3	Press Hold (2.5 S)	▲	The interface "8" flashed.
		4	Short Press	▲	Set address values from 81H to 91H.
		5	Press Hold (2.5 S)	▼	To save the present setting parameter and move forward to the display page.
5	Operation Mode Setting	1	Enter the setting interface, and the data saving.	<ul style="list-style-type: none"> • Automatic Mode: Upper computer control module start and stop. • Debugging Mode: The module starts up automatically, which is convenient to confirm the status of the module on site. 	
		2	Automatic Mode: -A-		
		3	Debug Mode: -C-		
6	Group Mode Setting	1	Enter the setting interface, and the data saving	Modify the module grouping mode and save the parameter after power off.	
		2	Fixed Packet Mode: -F-		
		3	Dynamic Packet Mode: -C-		

7	Protocols setting	1	State grid agreement: P01	Switchable Communication Protocol.	
		2	Bacancy Agreement: P02		
8	Elevation Mode	1	Normal Altitude Mode: 0-1 (Altitude within 2000 m)	Different application scenarios at different altitudes.	
		2	High Altitude Mode: 0-2 to 0-8 (Altitude between 2000m and 5500 m)		
9	Parameter Settings in Debug Mode	Voltage and current parameters can be set.			
		1	Press Hold (2.5 S)	▲ or ▼	The interface 500 appears. or The interface flashes in one bit.
		2	Press Hold (2.5 S)	▲	The interface 10 flashes.
		2.1	Short Press	▲	Change 500 to 550.
		2.2	Press Hold (2.5 S)	▲	The interface 100 flashing.
		2.3	Short Press	▲	Change 550 to 650.
		3	Press Hold (2.5 S)	▼	Save the current setting parameter and go to the display page.

7.3 Indicator LED Light




The indicator LED light is fully used to represent the functioning and fault status of the power module, which operates in three basic states: extinguished, always on, and flashing, with the arrangement and combination of the three indicators producing 27 states. There are several meanings for this, making it difficult to create a single specification that clarifies the exact meaning of each indication LED light.

Table 8 Definition of Indicator LED Light

No.	LED Colour	Description
1	Green 	To indicate the running state.
2	Yellow 	To indicate alarm information. (Not serious in nature and often caused by improper operation or environment factors.)
3	Red 	To indicate fault information. (When such problems occur, it usually leads to shut down. It is often a self-protection that exceeds the normal working limit of the module. Continued operation may cause irreversible damage to the module.)

A. State Grid Protocol Indicator

Table 9 Definition of State Grid Protocol Indicator

No.	Function	Description
1	Running Lights	<ul style="list-style-type: none"> Colour (): Green. Always OFF: NOAC input. Steady ON: There is an AC input, and the status is normal.
2	Protection Light	<ul style="list-style-type: none"> Colour (): Yellow. Always OFF: In the normal state, the charging module does not have a protective alarm. Steady ON: Possible issues include input overvoltage, undervoltage, phase loss, overheating in the environment, and address duplication. 0.5 Flickering: The communication between the module and the host computer is interrupted.
3	Fault Indicator	Colour (): Red Always OFF: In the normal state, the charging module is not faulty. Steady ON: Possible issues include output over-voltage, short circuit, fan failure, discharge failure, internal module over-heating, communication disruption, and non-recoverable non-output crashes.

B. Bacancy Agreement Indicator

















Table 10 Definition of Bacancy Agreement Indicator

No.	Function	Description
1	Steady Red Light	Input Abnormality (Overvoltage, Undervoltage, Phase Loss).
		Abnormal Busbar (Overvoltage, Undervoltage).
		Sci Communication (Abnormal communication of front and rear stage SCI).
		Output Overvoltage (Hardware Overvoltage, Software Overvoltage).
		PFC Abnormality (Pre-Stage Failure Shutdown).
		Fan Failure.
		Internal Overheating.
		Output Short Circuit.
		Bleed Failure.
		Bus Bais.
2	Solid Yellow Light Green Light	Output Undervoltage Warning.
		Output Overvoltage Warning.
3	Yellow Light Flashes, Green Light Stays On	Limited Power.
4	Green Light Flashing	Module Standby Without Failure.
5	Green Light	The Module Is Running Normally.
6	Red Light Yellow Light	CAN Communication Interrupted.

- **All LED Indicator**





When the power module is operational, three LEDs on the front panel illuminate to indicate the module's status. The following table shows module and LED status, with descriptions below.



Table 11 LED Status and Its Meaning

No.	Module Status	LED Colour	LED Status	Description
1	Normal Working	Green 	Steady	Normal Charging Status
2	Standby Status	Green 	Blinking	To Be Charged
3	Limited Power	Green 	Steady	When the module reaches to the power limited condition, the module will automatically limit the power.
		Yellow 	Blinking	
4	Output Overvoltage Alarm	Green 	Steady	Module output over/under voltage alarm
		Yellow 	Steady	
5	Communication Abnormal	Green 	Steady	After the communication between the module and the upper computer is interrupted for 20s, it will automatically shutdown and report the communication failure.
		Red 	Steady	
6	Output Overvoltage	Red 	Steady	Hardware or software overvoltage protection.
7	Input Abnormal	Red 	Steady	Input Over Voltage, Under Voltage, Phase Loss
8	Bus Abnormal	Red 	Steady	Bus Over Voltage
9	Fan Failure	Red 	Steady	Fan Resistance, Failure
10	Over-Temperature	Red 	Steady	When the ambient temperature or module internal temperature exceed the preset protection threshold, the system shuts down.
11	Output Short Circuit	Red 	Steady	Trigger Hardware Protection, Lock Down.
12	Discharge Fault	Red 	Steady	There is a discharge circuit inside the module. After the mode is shut down, the output voltage cannot drop below 48V within 1S.
13	Address Conflict	Red 	Steady	Multiple modules are used in parallel, and the same address appears.

8. Operating Environment

The power module is designed according to IP20 protection level, and the heat dissipation method is active air cooling. For typical usage, environmental conditions, stack protection design and system heat dissipation design need to be addressed.

PROHIBITION	Installation Environment Circumstance
	The product should not be installed near liquids, and it should not be installed under water-proof locations such as air conditioners, vents, or outlet windows in the equipment room to prevent liquids from entering the device and causing short circuits, as well as to ensure that there is no condensation near power module.
MANDATORY	Outdoor Protection
	In general, the level of outdoor protection should be greater than IP54.
PROHIBITION	Marine Environment, Pollution, Heavy Industries, and Mining
	<p>Prohibits the use of the product in the maritime environment or on outdoor area near a pollution source or in an area with only minimal sheltering.</p> <p>However, if the user intends to use the charging pile in the environment, the protection level should be greater than IP65, otherwise the product will malfunction. The sources of pollution include the following:</p> <ul style="list-style-type: none"> • 4 km radius from high salt content (such as the ocean) • 3 km away from severe pollution sources such metallurgy, coal mining, thermal power plants, chemicals, rubber, and electroplating. • 1 km away from low pollution sources such as food, leather, and heating burners.
PROHIBITION	Corrosive and Insulating Environment
	<p>The use of the product is restricted in corrosive and insulating environments.</p> <p>However, if the user intends to use the charging pile in the environment, the protection level should be greater than IP65, otherwise the product will malfunction.</p>

MANDATORY	Altitude Level
	The product shall be used within 2000 meters of altitude.
PROHIBITION	Risk of Fire / Flammable Materials
	Please avoid installing and using this equipment in places such as gas stations, gas stations, etc. that have safety and explosion-proof requirements for electrical equipment.

A. Heat Dissipation

The power module uses a DC axial fan to disperse heat. The power module uses a fan speed regulation approach to precisely change the fan speed, resulting in low temperatures and noise. Furthermore, the fan-induced power module loss can be decreased.

The heat dissipation of the charging station system can be designed based on factors such as the air volume and ambient temperature of the power module to reduce system power consumption and noise. For more information on the heat dissipation of the power module.

- **Fan Characteristics**

Parameter	Value
Air Volume (under zero static pressure)	120 CFM (3.4 m ³ /min)
Wind Pressure (At zero air volume)	3.21 inch-H ₂ O (81.54 mm-H ₂ O)

- **Air Volume required**


Parameter	Value
Power	30kW
Number of Fans	3
Minimum Air Volume Requirement	360 CFM
Increase Air Demand	420 CFM

The data above only represents the air volume requirements of a single power module. The ventilation volume of the system is estimated based on the total number of modules, excluding the air volume required by other devices.

Explanation:

1. The ambient temperature of the power module refers to the temperature at the air inlet of the fan.
2. The information is evaluated for a single power module with an air inlet and outlet which are not covered. The effect of system resistance on the functioning point of module fans should be addressed during system design.

• **PQ Curve of the Fan Used by the Power Module**




B. Reference Design for Heat Dissipation of Power Module

Anti-Hot Air Reflux Design: Hot air reflux occurs when all or a portion of the high-temperature air released from the power module's outlet is redirected to the power module's intake. As a result, the temperature at the inlet rises abnormally, interfering with the normal functioning of the power module. A typical backflow prevention design can be referred to as follows:

1. Cut off the hot air return channel

- Isolate hot and cold air from the power module's air inlet and outlet and close the hot air return channel. To avoid return air, install filler panels in the reserved places of the power module. To prevent air return between the power module and the installation place, use seals or sealing plates.



2. Air Volume Matching


- The total of the air volume at the operating point of all system fans should be more than the air volume required by the power module's hot air to avoid hot air accumulation caused by insufficient air exhaust capacity.
- Due to system resistance (such as blinds and air filters), the air volume at the operating position of the system fan is less than the maximum air volume stated in the fan specification.
- When selecting a system fan, the total maximum air volume indicated in the system fan specification must be 1.5 to 2 times the power module pile's hot air exhaust volume.
- Determine the operating point of the system fan using the fan PQ curve and the system resistance curve, and make sure that the total of the fan operating point air volume exceeds the power module pile's hot air exhaust volume.

3. Suggestions for Inlet and Outlet

- Because the working point of the power module fan is impacted by inlet and outlet air resistance, the user should charge the power module to guarantee smooth inlet and outlet air resistance.
- The inlet and outlet air resistance impact the power module's fan's working condition. The power module should be kept at a particular distance from the air intake and air exit to guarantee smooth operation.
- The distance between the power module and the air inlet must be at least 50 mm, and the module must be at least 100 mm from the air exit.
- The ventilation area of a single power module should be extended to 20000 mm², with a minimum of 15000 mm².
- The ventilation area of the charging station is computed by adding the number of power modules.

9. Maintenance

The maintenance instructions are provided here. Furthermore, in this user guide, the following sections must be followed to operate the power module efficiently and effectively.

MANDATORY	Disconnect Power Supply
	<p>The power source or plug should be disconnected in the event of an unanticipated event or when conducting maintenance and repair.</p>


1. The dustproof net of the cabinet should be cleaned and dedusted on periodic intervals to reduce dust accumulation in the air intake, which causes excessive temperatures within the module.
2. If the power module is in unrecoverable fault circumstances, replace it immediately.

9.1 Preventive Instruction

1. Periodically clean and dust the air filter of the cabinet to prevent dust from collecting in the air inlet, which may cause high temperatures inside the module, power limits, or even damage to the power module.
2. To ensure proper grounding, check the power module and the entire power module pile on a regular basis.
3. Check the operation of the power module fan and the system fans on a regular basis.
4. Check the rain protection on a regular basis to prevent rainwater from reaching the charging station's body.

9.2 Replacement


1. Disconnect the AC input circuit breaker from the malfunctioning power module and unscrew the screws on the front panel.
2. Hold the module handle with one hand and the power module body with the other hand and pull the power module out of the cabinet slowly.

CAUTION!	Burn
MANDATORY	Wear Protective Gloves
	<p>The surface of the power module may be hot; use protective gloves to avoid the burn.</p>

3. To replace the power module, follow the installation instructions (Section 6).
4. Turn on the AC input circuit breaker for the power module.
5. Check that the monitoring module can recognize the newly replaced power module (State Grid Protocol needs manual address configuration) and that the new power module flows in the same way as the previous power modules.
6. If every components are normal, it means that the process went smoothly, and the replacement is completed.

10. Appendix


10.1 Dispose of Product

Disposal	Product Disposal and Recycling
	<p>Out-of-service products should be handed over to the recycling industry, dealers, or manufacturers.</p>

10.2 Abbreviations and Glossary


°C	<i>The degree Celsius (symbol: °C) can refer to a specific point on the Celsius temperature scale or to a difference or range between two temperatures.</i>
3P+N+PE	<i>A 3-phase 4-wire + PE system is an electrical power distribution system that consists of three conductors carrying alternating current (AC) power, a neutral conductor, and a protective earth conductor.</i>
A	<i>An ampere is a unit of measure of the rate of electron flow or current in an electrical conductor.</i>
AC	<i>Alternating current, is a type of electrical current in which the current repeatedly changes direction.</i>
ALM	<i>Alarm</i>
APFC	<i>Automatic Power Factor Correction (APFC) is a technology used in electrical systems to improve the power factor, which is a measure of how efficiently electrical power is used.</i>
CAN	<i>A controller area network (CAN) bus is a high-integrity serial bus system for networking intelligent devices. CAN busses and devices are common components in automotive and industrial systems.</i>
dB	<i>Decibel (dB), a unit for expressing the ratio between two physical quantities, usually amounts of acoustic or electric power, or for measuring the relative loudness of sounds. One decibel (0.1 bel) equals 10 times the common logarithm of the power ratio.</i>
DC	<i>Direct current (DC) is one-directional flow of electric charge.</i>
DSP	<i>Digital Signal Processing (DSP) involves the representation, processing, modeling, and analysis of signals, information, and physical phenomena.</i>
EMC	<i>Electromagnetic compatibility (EMC) is the ability of electrical systems and equipment to operate together without interfering with each other.</i>

EV	<i>An EV is defined as a vehicle that can be powered by an electric motor that draws electricity from a battery and is capable of being charged from an external source.</i>
Hz	<i>hertz, the SI unit of frequency, is equal to one cycle per second.</i>
IP	<i>Ingress Protection (IP) ratings, which grade the resistance of an enclosure against the intrusion of dust or liquids.</i>
kW	<i>kW is a kilowatt. kW is used to represent the actual power that carries out the work.</i>
LED	<i>A light-emitting diode (LED) is a semiconductor device that emits light when current flows through it.</i>
LLC	<i>It means two coils and one capacitor. This integrated circuit has one function: To harmonize the alternating current, by transforming square patterns, which are typical for capacitor circuits, into sinusform waves, which highly increase efficiency.</i>
mm	<i>The millimetre is a unit of length in the International System of Units (SI), equal to one thousandth of a metre.</i>
MΩ	<i>Symbol for megaohm, an SI unit of electrical resistance equal to 10⁶ ohms</i>
PE	<i>A protective earth connection, earth ground, or safety ground uses a protective conductor to safely direct a fault current into the earth and away from a human being in contact.</i>
PFC	<i>PFC stands for Power Factor Correction, which is a set of mechanisms in a power supply circuit that improve the power factor (PF).</i>
s	<i>The second (symbol: s) is the unit of time.</i>
V	<i>Voltage, also known as (electrical) potential difference, electric pressure, or electric tension is the difference in electric potential between two points.</i>
VAC	<i>VAC (Volts Alternating Current) is a measure of the strength of the alternating electric field that drives the flow of electrons in AC electrical systems.</i>
VDC	<i>VDC refers to volts of direct current, and it can come from either a battery or a power supply that converts AC (alternating current) into DC.</i>
Ω	<i>A unit of electric resistance equal to the resistance of a circuit in which a potential difference of one volt produces a current of one ampere.</i>

 **Bacancy Systems PVT LTD,**
15-16, Times Corporate Park,
Near Thaltej-Shilaj Road,
Opp. Copper Stone Flats,
Thaltej, Ahmedabad,
Gujarat, India, 380059

 www.bacancysystems.com

 systems@bacancysystems.com

 +91 90160 28817

 **Helpdesk:** <https://bacancy.freshdesk.com/a/dashboard/default>